


# RACK PAL INSTALLATION MANUAL



[www.cogan.com](http://www.cogan.com)




Copyright © October 2008, Cogan Wire and Metal Products Ltd.

All rights reserved




**Cogan**<sup>®</sup> **FASTER.  
LEANER.  
BETTER.™**


# ANCHORING



Hammer drill a hole  
same nominal diameter  
and at least as deep  
as the length of anchors



Clean hole with  
blow out bulb



Ø5/8" x 4 1/2" min bolts  
(anchors) are used  
for baseplates



Drive the hilti bolt in the hole  
so that at least **6 threads** are  
below the top surface of fixture.  
Then tighten to the recommended  
torque value to achieve proper  
anchor setting

